



NOTES: AREA AROUND DRAIN SHOULD BE DEPRESSED/SUMPED (SEE DRAWING) TO PROMOTE POSITIVE WATER DRAINAGE.

REINFORCEMENT SHALL BE ONE SHEET EXTENDING A MINIMUM OF 300 mm BEYOND THE DRAIN FLANGE ON ALL SIDES AND SECURED IN CLAMPING RING AT DRAIN.



MONOLITHIC
 MEMBRANE
 #6125
 WATERPROOFING SYSTEMS

TYPICAL DRAIN DETAILS

HYDROTECH MEMBRANE CORP.

NO SCALE

WC-8A